

90 O'Leary Drive, Bensenville, Illinois 60106, U.S.A. Telephone: (312) 860-6400




WARNING: THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTIONS MANUAL, MAY CAUSE INTERFERENCE TO RADIO COMMUNICATIONS. AS TEMPORARILY PERMITTED BY REGULATION IT HAS NOT BEEN TESTED FOR COMPLIANCE TO SUBPART J OF PART 15 OF FCC RULES, WHICH ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST SUCH INTERFERENCE. OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE INTERFERENCE IN WHICH CASE THE USER AT HIS OWN EXPENSE WILL BE REQUIRED TO TAKE WHATEVER MEASURES MAY BE REQUIRED TO CORRECT THE INTERFERENCE.

Installation and General Game Operation Instructions INDEX

	·	PAGE
l.	INSTALLATION	1
IJ.	GENERAL GAME OPERATION	2
III.	BOOKKEEPING FUNCTIONS	3
IV.	FEATURE OPERATION AND SCORING	4
V.	GAME ADJUSTMENTS	5
	A. PLAYFIELD ADJUSTMENTS	5
	B. BACKBOX ADJUSTMENTS	5
	CREDITS/COIN	5
	MAXIMUM CREDITS	6
	BALLS/GAME	6
	MATCH FEATURE OPTION	6
	CREDIT DISPLAY	6
	HIGH SCORE FEATURE OPTION	6
	HIGH SCORE TO DATE	6
	GAME FEATURE OPTIONS	7
	SOUND OPTION	7
	C. FRONT DOOR GAME ADJUSTMENTS	
	HIGH SCORE FEATURE	8
	HIGH SCORE TO DATE FEATURE	8
VI.	RECOMMENDED SCORE CARDS	. 11
VII.	RECOMMENDED SETTINGS	. 12
VIII.	ROUTINE MAINTENANCE ON LOCATION	4
IX.	TROUBLE SHOOTING ON LOCATION	. 13
Χ.	SERVICE/PARTS	. 19
XI.	PARTS LIST	
		3

BLOCK DIAGRAM—ELECTRONIC PINBALL GAME



I. INSTALLATION

Assemble the game as follows:

Bolt legs to cabinet. Bolt back box to cabinet. Use flat washers under bolt heads. Gently feed cable connectors and ground braid through cable port in back box. Screw ground braid to braid in back box. Carefully and fully insert connectors on printed circuit assemblies.

On all games there are certain items that should be checked after shipment. These are visual inspections which may avoid time consuming service work later. Minor troubles caused by abusive handling in shipment are unavoidable. Cable connectors may be loosened, switches (especially tilt switches) may go out of adjustment. Plumb bob tilt switch should always be adjusted after game is set on location and leg levelers are adjusted.

Visual inspections before plugging in line cord:

- 1. Check that all cable connectors are completely seated on printed circuit assemblies.
- 2. Check that cables are clear of all moving parts.
- **3.** Check for any wires that may have become disconnected.
- **4.** Check switches for loose solder or other foreign material that may have come loose in shipment and could cause shorting of contacts.
- **5.** Check wires on coils for proper soldering. Cold solder connections may not show up in factory inspection, but vibration in shipment may break contact.
- 6. Check that fuses are firmly seated and making good contact.
- 7. Check the transformer for any foreign material shorting across wiring lugs.
- 8. Check wiring of transformer to correspond to location voltage. See figure 1.

Check adjustment of the three (normally open) tilt switches:

- 1. Panel tilt on bottom of playfield panel.
- 2. Plumb bob tilt on left side of cabinet near front door.
- **3.** Ball tilt above plumb bob tilt. Insert the smaller ball (15/16" dia.) into the ball tilt assembly, and adjust the bracket so the ball will roll free to contact the switch blade, if front of cabinet is raised.

TRANSFORMER CONNECTION INSTRUCTIONS

REFER TO POWER SUPPLY SCHEMATIC IN GAME MANUAL FOR TABLE "A"

115 VAC,	2-8, 3-6, 7-10
120 VAC,	2-8, 4-6, 7-11
220 VAC,	4-8, 7-9
240 VAC,	4-8, 7-11

II. GENERAL GAME OPERATION

Place ball into playfield by outhole.

Coin game. Coin should be rejected. Plug in line cord. Move power ON-OFF master switch at bottom right front corner of cabinet to 'ON' position. The game will play a power-up tune to announce game-readiness. Drop targets are reset, scores are set to zero, alternating with the 'High Score to Date,' and the game is ready for play. Coin game. The game should accept the coin and post credits* for coins accepted (adjustable). Pressing the credit button on the door will cause the outhole kicker to serve the ball to the shooter alley. The 1st player-up lite is lit. A game-up tune* is played to announce play-readiness.

One player is posted each additional time the credit button is pressed (one to four can play). The credits are reduced by one each time the credit button is pressed until the credits are reduced to zero.

Shooting the ball initiates play.

The game awards all points earned by the player. If spinner is turning and scoring when the ball hits a target, the spinner and the target scores are awarded.

When the ball enters the outhole, the bonus score is added to the total score. The player-up and/or ball in play on the back box is advanced one position. The outhole kicker serves the ball to the shooter alley and play is resumed. This continues until each player has played the allowable number of balls per game (adjustable). At this time the 'Game Over' light is lit. A random Match* number appears and the 'Match' light is lit. If the number is the same as the last two digits in a player's score, a free game is awarded.

Extra balls won during the course of the game are played immediately after the player's regular ball enters the outhole. The player-up and/or ball in play on the back box are not advanced for extra ball play. Bonus score is added to the player's score before the game serves the extra ball for play.

Scoring over 10,000,000 gives "High Score to Date" award.

At the end of the game, a 'High Score to Date' is alternately flashed with all 4 player scores. If the 'High Score to Date' is beat, this feature* awards free games.

Tilting the game results in loss of a ball. The flippers, thumper-bumpers, etc., go 'dead'. Bonus points are not scored. The purpose of the tilt penalty is to discourage the player from jostling the machine in an attempt to prolong play. Game action becomes normal after the ball kicker assembly serves the ball to the shooter alley.

Slamming the machine results in loss of the game. All feature lights go out, the game goes 'dead,' and a time delay occurs. The purpose of the time delay is to discourage unnecessary abuse of the machine. After the delay, the 'Game Over' light lites and the power-up tune is played. The time delay occurs anytime one of the slam switches is made to contact. There are two factory installed slam switches, on the front door, and one on left side of cabinet. (Any number of slam switches could be installed by the operator, to meet his individual requirement.) The switch should be adjusted to have approximately 1/16" gap between the contacts. The weighted blade should be adjusted to attain the desired sensitivity. Decreasing the gap between contacts will make the switch more sensitive. Opening the gap will reduce sensitivity.

^{*}Some tunes and features can be disabled by operator if so desired. See Back Box Adjustments. **NOTE:** Scoring and feature units will differ from game to game.

III. BOOKKEEPING FUNCTIONS

The game is designed to help the operator perform certain accounting functions. The game can display the number of total plays and replays (free games). It can display the number of coins dropped down each coin chute. The bookkeeping functions are displayed on all player score displays simultaneously. An identification number, 05 to 15, appears on the Match/Ball in Play window as follows:

```
40 = Current Credits
05-
          00 to-
*06—100000 to—99999 = Total Plays (Payed & Free Games)
*07— 10000 to—99999 = Total Replays (Free Games)
08 - 
          00 to -99999 = Game Percentage
          00 to—99999 = Total times 'High Score to Date' is beat
09 - 
*10— 10000 to—99999 = Coins Dropped thru Coin Chute #1
*11— 10000 to—99999 = Coins Dropped thru Coin Chute #2**
*12— 10000 to—99999 = Coins Dropped thru Coin Chute #3**
          00 to—99999 = Number of Specials awarded from Panel Specials Only
*13---
*14---
          00 to—99999 = Number of minutes of Game Play
*15---
          00 to—99999 = Number of Service Credits
```

The game displays the first bookkeeping entry if the Self-Test button (See Fig. III) on the inside of the front door is pressed ten times. Alternately push and release the Self-Test button at one second intervals. The number 05 appears in the 'Match/Ball in Play' window. Current credits appear on the player score displays. Each additional press of the button causes the next entry to be displayed.

After the data in each bookkeeping register is recorded, it can be set to zero simply by pressing switch button S33, located on A4, the MPU module in the back box (See Fig. III), or by pressing the Coin Chute #3 switch. Any or all registers can be cleared by alternating between the Self-Test button and the switch button S33 on the MPU module or Coin Chute #3 switch. The operator is given this option as a possible convenience and can elect to use or not use it as his needs direct.

Pressing the button 5 more times causes the game to play the power-up tune and light the Game Over light.

Service credits are designed to allow the serviceman to test the game under actual play conditions without disturbing the bookkeeping records that reside at identification numbers 06, 07, 10, 11 and 12.

To obtain Service Credits, push and release the Self-Test switch until identification number 05 appears in the 'Match/Ball in Play' window. Hold in the Credit button until the desired number of Service Credits (up to five) appears on the player score displays.

NOTE: If, upon accessing identification number 05, a number of credits greater than five is displayed, pressing the credit button has no effect.

Identification number 15 is reserved as a record of the number of Service Credits used.

NOTE: If "Total Play" register is reset to zeroes then "Total Replays" register should also be reset to zeroes to maintain the game percentage value.

^{*}The 10,000 level is pre-set at the factory; can be set to zero, initially, if desired.

^{**}If Coin Chute is not used in game, number displayed (if other than 00) on Player Score displays has no significance.

#1215 FLASH GORDON FEATURE OPERATION & SCORING

A. BONUS FEATURE

Two separate bonus of 1000 to 19,000 may be scored. The top bonus applies to the upper level and the bottom bonus to the lower level. The top bonus advances one step at a time each time a drop target is knocked down, the stand up target is hit, the two left and the two right rollover buttons are activated but only after the drop target bank is knocked down.

The single drop target scores two bonus advances at all times, the bottom bonus advances one step at a time each time a drop target is knocked down, a stand up target is hit, the two inside lanes are lit outlane rollovers score two bonus advances at all times.

B. BONUS COLLECT AND BONUS MULTIPLIERS FEATURE

When the ball goes into the outhole, the top stand up target is lit for collect top bonus or the ball shooter lane is lit for collect bottom bonus, the lit bonus score is added to the player's total score. If 2X, 3X, 4X or 5X is lit the score will be twice three, four or five times. A tilt nullifies the bonus score.

The bonus multipliers are lit in this order, knocking down second inline drop target lites 2X, the third one lites 3X, then knocking down top drop target bank lites 4X and knocking down left bottom drop target bank lites 5X.

Switch #16 Memory for Multipliers

ON: Liberal

OFF: Conservative

C. MINI BONUS AND SUPER BONUS FEATURE

If knocking down a top drop target with 1-2-3 flashing, the arrow remains lit, lighting 1-2-3 lites the mini bonus for 50,000 to be rewarded in the outhole.

Switch #24 Memory for 1-2-3

ON: Liberal

OFF: Conservative

If knocking down a left bottom flashing drop target, the light remains lit and making matching colors at 2 right targets and flipper return lanes, lites the super bonus for 100,000, to be rewarded in the outhole.

Switch #23 Memory for drop target colors

ON: Liberal

OFF: Conservative

Switch #22 Memory for matching colors

ON: Liberal

OFF: Conservative

D. 2X, 3X, 5X PLAYFIELD VALUES FEATURE

Making the mini bonus lites saucer for 2X playfield values for 15 seconds which means that every value on the playfield is double. Making the super bonus lites saucer for 3X playfield values for 15 seconds which means that every value on the playfield is triple. Making saucer while 2X and 3X are lit will increase playfield values to 5X also for 15 seconds.

Switch #8 Memory for 2X and 3X playfield values.

ON: Liberal

OFF: Conservative

E. TOP DROP TARGETS FEATURE

Making drop targets,

1st time lites thumper bumper for 5K.

2nd time lites stand up target for collect bonus, top level only.

3rd time lites stand up target for SPECIAL.

Switch #15 Memory for top special

ON: Liberal

OFF: Conservative

F. BOTTOM LEFT DROP TARGETS

Making drop targets,

1st time lites left spinner and saucer for 10K.

2nd time lites right spinner and saucer for 30K.

3rd time lites saucer for 60K.

4th time lites saucer for extra ball.

5th time lites outlane SPECIALS.

Switch #6 Memory for saucer 10K

ON: Liberal

OFF: Conservative

Switch #7 Memory for saucer values

ON: Liberal

OFF: Conservative

Switch #14 Memory for outlane specials

ON: Liberal

OFF: Conservative

G. INLINES EXTRA BALL FEATURE

Knocking down inline drop targets lites stand up target for Extra Ball.

Switch #30 Memory for extra ball

ON: Liberal

OFF: Conservative

H. COLLECT BONUS FEATURE

Knocking down top single drop target lites ball shooter lane for collect bonus, bottom level only.

I. SPECIAL REPLAY/X-BALL/NOVELTY MODES

Self test positions 16 and 17 give the operator flexibility to award a replay, extra ball or score (Novelty) when a special is scored. A combination of X/Ball, Novelty, Novelty can be obtained through the following chart:

Self test position 16	Set to "03"	Set to "02"	Set to "01"
Playfield X-Balls and Specials	Award	Award	Award
Left or right out Special Top target special	REPLAY	X-Ball*	50,000
	REPLAY	X-Ball*	50,000
Inline drop target X-Ball	X-Ball	X-Ball**	25,000
Saucer X-Ball	X-Ball	X-Ball**	25,000
Self-test position 17	Set to "03"	Set to "02"	Set to "01"
	Award	Award	Award
Scoring Thresholds	REPLAY	X-Ball**	25,000

^{(*) 50,000} if same player shoot again is lit.

^{(**) 25,000} if same player shoot again is lit.

V. GAME ADJUSTMENTS

A. Playfield Panel Post Adjustments:

Posts that control left and right outlane opening on panel can be removed to make access to outlanes easier or harder for ball to enter. See Figure II.

Easier entry will decrease playing time and scoring (conservative).

Harder entry will increase playing time and scoring (liberal).

B. Back Box Game Adjustments:

Each game has thirty-two switches located on A4, the MPU module, located in the back box, that allow play to be customized to the location. See Figure III. Credits per coin, maximum credits, credit display, balls per game, match feature, high game feature, special award and melody are selectable by means of the switches. The switches are contained in four-sixteen lead packages numbered S1-8, S9-16, S17-24, and S25-32 for easy identification. The "ON" toggle position is marked on the assembly. **Turn off power before making adjustments.**

Credits/Coin Adjustments:

The credits per coin are selectable by means of S17-S20 for coin chute #2 (Center). The switch settings and resultant credits/coin are as follows:

S19	S18	S17	Credits/Coin	S20	S19	S18	S17	Credits/Coin
OFF	OFF	OFF	Same as Coin Chute #1 Settings	ON	OFF	OFF	OFF	8/1 Coin
OFF	OFF	ON	1/1 Coin	ON	OFF	OFF	ON	9/1 Coin
OFF	ON	OFF	2/1 Coin	ON	OFF	ON	OFF	10/1 Coin
OFF	ON	ON	3/1 Coin	ON	OFF	ON	ON	11/1 Coin
ON	OFF	OFF	4/1 Coin	ON	ON	OFF	OFF	12/1 Coin
ON	OFF	ON	5/1 Coin	ON	ON	OFF	ON	13/1 Coin
ON	ON	OFF	6/1 Coin	ON	ON	ON	OFF	14/1 Coin
ON	ON	ON	7/1 Coin	ON	ON	ON	ON	15/1 Coin
	OFF OFF OFF ON ON	OFF OFF OFF ON OFF ON OFF ON OFF ON OFF	OFF OFF OFF ON OFF ON OFF ON OFF ON OFF ON ON OFF ON ON ON ON ON OFF ON ON ON OFF	OFF OFF OFF Same as Coin Chute #1 Settings OFF OFF ON 1/1 Coin OFF ON OFF 2/1 Coin OFF ON ON 3/1 Coin ON OFF OFF 4/1 Coin ON OFF ON 5/1 Coin ON ON OFF ON 6/1 Coin	OFF OFF OFF Same as Coin Chute #1 Settings ON OFF OFF ON 1/1 Coin ON OFF ON OFF 2/1 Coin ON OFF ON ON 3/1 Coin ON ON OFF OFF 4/1 Coin ON ON OFF ON 5/1 Coin ON ON ON OFF 6/1 Coin ON	OFF OFF OFF Same as Coin Chute #1 Settings ON OFF OFF OFF ON 1/1 Coin ON OFF OFF ON OFF 2/1 Coin ON OFF OFF ON ON 3/1 Coin ON OFF ON OFF OFF 4/1 Coin ON ON ON OFF ON 5/1 Coin ON ON ON ON OFF 6/1 Coin ON ON	OFF OFF OFF Same as Coin Chute #1 Settings ON OFF OFF OFF OFF ON 1/1 Coin ON OFF OFF OFF ON OFF 2/1 Coin ON OFF ON OFF ON OFF ON ON OFF ON ON OFF ON ON OFF ON OFF ON ON ON OFF ON ON ON ON ON OFF 6/1 Coin ON ON ON ON	OFF OFF OFF Same as Coin Chute #1 Settings ON OFF OFF OFF OFF OFF ON 1/1 Coin ON OFF OFF ON ON OFF ON ON ON ON ON ON OFF ON OFF ON ON ON ON ON ON OFF ON ON ON ON ON OFF ON ON ON ON ON ON OFF ON ON

The credits given are selectable by means or switches 1-5 incl., for coin chute #1 and switches 9-13 incl., for coin chute #3. Thirty-one different credit ratios are available for each coin chute. The switch settings and resultant credits/coin are listed below.

CREDITS/COIN ADJUSTMENTS

											TOTAL	
COIN CHUTE		:	SWITC			CREDITS	CREDITS	CREDITS	CREDITS	CREDITS	CREDITS/COIN	IS
#1 (HINGE SIDE)	.5	4	3	2	1							
OR #3	13	12	11	10	9							
(RIGHT SIDE)	OFF	OFF	OFF	OFF	OFF	1/1 Coin						
	OFF	OFF	OFF	OFF	ON	2/1 Coin						
	OFF	OFF	OFF	ON	OFF	3/1 Coin						
en was	OFF	OFF	OFF	ON	ON	4/1 Coin						
	OFF	OFF	ON	OFF	OFF	5/1 Coin						
	OFF	OFF	ON	OFF	ON	6/1 Coin						
	OFF	OFF	ON	ON	OFF	7/1 Coin						
	OFF	OFF	ON	ON	ON	8/1 Coin						
	OFF	ON	OFF	OFF	OFF	9/1 Coin						
	OFF	ON	OFF	OFF	ON	12/1 Coin						
	OFF	ON	OFF	ON	OFF	14/1 Coin						
	OFF	ON	OFF	ON	ON	1/2 Coins*						
	OFF	ON	ON	OFF	OFF	2/2 Coins*						
	OFF	ON	ON	OFF	ON	3/2 Coins*						
	OFF	ON	ON	ON	OFF	4/2 Coins*						
	OFF	ON	ON	ON OFF	ON	5/2 Coins*						
	ON	OFF	OFF		OFF	6/2 Coins*						
	ON	OFF OFF	OFF OFF	OFF ON	ON OFF	7/2 Coins*						
	ON	OFF	OFF	ON		8/2 Coins*						
	ON ON	OFF	ON	OFF	ON OFF	9/2 Coins* 12/2 Coins*						*
	ON	OFF	ON	OFF	ON	14/2 Coins*						
	ON	OFF	ON	ON	OFF	1/1st Coins	2/2nd Coin				3/2	
	ON	OFF	ON	ON	ON	0/1st Coin*	1/2nd Coin	440 40 4	1/4th Coin		3/4	
	ON	ON	OFF	OFF	OFF	0/1st Coin*	1/2nd Coin	1/3rd Coin	1/4th Coin 2/4th Coin		3/4	
	ON	ON	OFF	OFF	ON	1/1st Coin	1/2nd Coin	0/3rd Coin** 1/3rd Coin	2/4th Coin		5/4 5/4	
	ON	ON	OFF	ON	OFF	1/1st Coin	2/2nd Coin	1/3rd Coin	3/4th Coin		7/4	
	ON	ON.	OFF	ON	ON	1/1st Coin	2/2nd Coin	2/3rd Coin	2/4th Coin		7/4	
	ON	ON	ON	OFF	OFF	0/1st Coin***	0/2nd Coin***	1/3rd Coin	2/401 COM		1/3	
	ON	ON	ON	OFF	ON	0/1st Coin**	0/2nd Coin**	0/3rd Coin**	1/4th Coin			
	ON	ON	ON	ON	OFF	0/1st Coin****	0/2nd Coin****	0/3rd Coin****	0/4th Coin****	1/5th Coin	1/5	
	ON	ON	ON	ON	ON	0/1st Coin***	0/2nd Coin***	1/3rd Coin	0/4th Coin****	1/5th Coin	2/5	
**! 0 " " " "	J	J. 4	314	014	014	57 TSL OOM	or End Oom	17 314 00111	0/ 1 01 0011	1/301100111	2/3	

^{*}No Credits until 2nd coin is dropped.

^{**}No Credits until 4th coin is dropped.

^{***}No Credits until 3rd coin is dropped.

^{****}No Credits until 5th coin is dropped.

MAXIMUM CREDITS:

The maximum credits accepted by the machine limits the number of games that can be accumulated by coining, by winning replays or both. The maximum number of credits is selectable by means of switches 25 and 26. Four credit limits are available. Switch settings are listed below.

SWIT	CHES
26	25
OFF	OFF
OFF	ON
ON	OFF
ON	ON
	OFF OFF ON

BALLS PER GAME:	# BALLS/GAME	SWITCHES	32	31
	5		OFF	ON
	4		ON	OFF
	3		OFF	OFF
	2		ON	ON

MATCH FEATURE:

When the Match Feature is ON, a random number appears on the Match/Ball in Play window and the word Match is illuminated. If the number matches the tens digit in a player's score, a free game is awarded. The Match Feature creates an incentive to play.

	MATCH	SWITCH 28
	ON	ON
	OFF	OFF
CREDIT DISPLAY:	CREDITS DISPLAYED	SWITCH 27
CHEDIT DISPLAY.	CHEDITO DIOPLATED	SWII CH 21
CREDIT DISPLAT.	YES	ON ON

HIGH SCORE FEATURE:

The game is designed to award an Extra Ball or Free Game at each of the two or three score levels. See Front Door Game Adjustments.

SELF TEST	SELF TEST
POSITION 16	POSITION 17
SET TO "03"	SET TO "03"
SET TO "02"	SET TO "02"
SET TO "01"	SET TO "01"
SET TO "00"	SET TO "00"
	POSITION 16 SET TO "03" SET TO "02" SET TO "01"

For combinations of replay/X-ball/Novelty Modes see page 4A "K. Special Replay/X-ball/Novelty Modes"

HIGH SCORE TO DATE OR OVER 10,000,000 SCORE FEATURE:

The game is designed to award free games as an option if high score to date is beat or player exceeds 10,000,000 points. Each time this happens, the winning score becomes the new high score to beat. This score is displayed on all 4 player score displays at the end of each game as an incentive to play. Recommended setting is underlined.

HIGH SCORE TO DATE FEATURE	SELF TEST POSITION 19
No Award	SET TO "00"
One Credit	SET TO "01"
Two Credits	SET TO "02"
Three Credits	SET TO "03"
The state of the s	

State and local laws may regulate the use of the above features, and they have been designed to allow for appropriate adjustment in order to conform to such requirements.

(**) 25,000 if same player shoot again is lit.

SOUND OPTION

The game is designed to make several tones and noises to announce power-up, game-up, etc. The tones are intended to attract attention to the game and increase game usage. The tones are controlled by pressing self test button until the #18 shows on the match/ball in play display. Now pulse replay button to desired sound setting.

Setting "00"

Most switches associated chimes without feature background.

Settina "01"

Playfield switches associated chimes with background.

Setting "02"

Most scoring will have noise effect without background.

Settina "03"

Most all scoring will have a noise effect with background.

GAME FEATURE OPTIONS:

Saucer 10,000 lite adjustment:

Liberal SW. 6 ON

10K is on at start of game.

Conservative

SW. 6 OFF

10K is not on at start of game.

Saucer values lite adjustment:

Liberal Conservative

SW. 7 ON SW. 7 OFF Any lit value will come on for next ball. Any lit values will not come on for next ball.

Saucer 2X, 3X arrow lite adjustment:

Liberal

SW. 8 ON SW. 8 OFF Any lit arrow will come on for next ball.

Any lit arrow will not come on for next ball.

Outlane specials lite adjustment:

Liberal

SW. 14 ON

Lit special lites will come on for next ball.

SW. 14 OFF Conservative

Conservative

Lit special lites will not come on for next ball.

Top target special lite adjustment:

Liberal Conservative SW. 15 ON

Lit special lite will come on for next ball.

SW. 15 OFF Lit special lite will not come on for next ball.

2X, 3X, 4X, 5X bonus lite adjustment:

Liberal Conservative **SW. 16 ON SW. 16 OFF** Any lit bonus lite will come on for next ball.

Any lit bonus lite will not come on for next ball.

2 Side targets and flipper feed lanes lite adjustment:

Liberal

SW. 22 ON

Any lit lites will come on for next ball.

Conservative

SW. 22 OFF

Any lit lites will not come on for next ball.

4 Drop target lite adjustment:

Liberal

SW. 23 ON

Any lit lites will come on for next ball.

Conservative

SW. 23 OFF

Any lit lites will not come on for next ball.

Top 3 target arrow lite adjustment:

Liberal

SW. 24 ON

Any lit arrow will come on for next ball.

Conservative

SW. 24 OFF

Any lit arrow will not come on for next ball.

Number of games replays per game adjustment:

Liberal

SW. 29 ON

All replays earned will be collected.

Conservative

SW. 29 OFF

Only 1 replay per player per game.

Inline extra ball lite adjustment:

Liberal Conservative SW. 30 ON **SW. 30 OFF** 1 extra ball per ball can be collected.

Only 1 extra ball per game can be collected.

Game over attract adjustment:

SW. 21 ON

Voice says "Emperor Ming Awaits"

SW. 21 OFF

No Voice

C. FRONT DOOR GAME ADJUSTMENTS

High Score Feature Adjustments:

The game is designed to award an extra ball (option) or a free game at each of three score levels. The recommended levels are on the score card in the game.

Any level from 10,000 to 9,999,000 can be set, as desired. It is also possible to reset or turn off (00) any or all of the levels, if desired.

- 1. Push and release Self-Test button (See Figure III) at one second intervals approximately six times or until identification number 01 appears on the 'Match/Ball in Play' display.
- 2. The number on the Player Score Displays is the score level.* It can be increased, if desired, by holding the credit button in. To decrease the score level, hold the credit button in and depress and release the Self-Test button. Release the credit button when the desired number appears. Note that the level changes 10,000 points at a time. If the number '00' is left on the displays, the high score feature is eliminated for that level.
- **3.** Repeat steps 1 and 2 for the second and third score levels. The identification numbers '02' and '03' on the Match/Ball in Play display are for the second and third levels, respectively.

High Score to Date and 10,000,000 Feature:

The game is designed to award free games when 'High Score to Date' is beat, or if the player exceeds 10,000,000 points.

It is recommended that the level, which will build with play, be periodically reset to the factory recommended level to encourage game play. The adjustment procedure is the same as for the High Score Feature Adjustment, Steps 1 and 2. Continue pushing the Self-Test button until the identification number '04' appears on the 'Match/Ball in Play' display and then do Step 2.

Any level from '00' to 9,990,000 can be set as described. It is to be noted that '00' does NOT turn off the feature, as it does on High Score feature. The feature is turned off by self test position 19 as discussed under 'Back Box Game Admustments'.

SELF TEST SETUP FOR 16-19:


To set up positions 16-19 push and release self test button till 16 shows on match/ball in play. Now pulse replay button for recommended setup from "00" thru "03." Repeat for positions 17, 18 or 19.

SOUND

In addition to individual volume controls for speech and other game sounds on the Sounds Plus Board. There is also a Master Volume Control located on the front door. (refer to page 10)

Please note that these module volume controls should be adjusted prior to setting the control on the front door.

*Can be quickly set to '00' by pressing S33 on the MPU assembly in the back box or Coin Chute switch #3. (See Figure III).



#1215 FLASH GORDON

A.	R-521-2	11/2" DIA.	(1)
B.	R-521-1	. 1" DIA.	(1) (5) (3)
C.	R-521-5	3" DIA.	(3)
D.	R-521-	¾" DIA.	(3)
E.	R-521-4	21/2" DIA.	(3)
F.	R-521-3	2" DIA.	
	R-533-3	FLIPPER	(1) (2)

PANEL TOP PARTS

Bottom Arch Shooter Gage Panel Plastics	P-5871-82 P-6359-47 M-1330-180
Panel Plastics	A-2890-149
Thumper Bumper Caps	A-3713-68 (3)
	C-900 (7)
Target Assy. (Yellow)	ASE-2911-21
	ASE-2993-10
	A-3032-64
Ball Guide Assy.	A-3032-65
	ASE-2795-81
	ASE-2214-29
	ASE-2250-83
	ASE-2250-84
Eject Hole Assy.	ASE-3054-1
Target Assy. Red	ASE-2911-3
	ASE-2993-11
(4) Drop Target Assy.	ASE-2795-82
	ASE-2806-1 (2) M-121-59 (2)
	M-121-59 (2)
Ball Guide Assy.	A-2898-39
	ASE-2214-21 (2)
	M-121-53 (2)
	A-2989-38
	ASE-2806 (2)
	ASE-2806-31
	P-8155-1
Ball Ramp (C)	P-8155-2
Ball Ramp (R)	P-8155-3
Ball Ramp (Lane)	P-8155-4
Target Assy. (Red)	ASE-2911-31 (2)
Minipost & Rubbér	ASE-2836-1 (4)
	Shooter Gage Panel Plastics Panel Plastics Thumper Bumper Caps Rollover Button Target Assy. (Yellow) (1) Inline Target Assy. Ball Guide Assy. Ball Guide Assy. (3) Drop Target Assy. Flipper & Shaft Assy. Spinner & Gate Assy. Spinner & Gate Assy. Eject Hole Assy. Target Assy. Red (3) Inline Target Assy. (4) Drop Target Assy. Rollover Wire Assy. Ball Guide Wire Ball Guide Assy. Flipper & Shaft Assy. Buffer Wire Ball Guide Assy. Rollover Wire Assy. Rollover Wire Assy. Rollover Wire Assy. Ball Ramp (L) Ball Ramp (C) Ball Ramp (R) Ball Ramp (Lane) Target Assy. (Red)

CONS. - CONSERVATIVE MED. - MEDIUM LIB. - LIBERAL

INDICATES MOVEABLE POSTS FOR SCORING ADJUSTMENTS




FIGURE III. ELECTRONIC PIN BALL MACHINE

RECOMMENDED

Instruction, Score Cards and High Score Feature Settings to be used on **FLASH GORDON 1215**

2	_	R	Λ	ı	ı
•	-		-		

5-BALL

REPLAYS

M-1508-96-E

Score Card 1 Replay at 600,000 1 Replay at 1,100,000

Instruction Card

M-1508-96-B

Score Card 1 Replay at 800,000 1 Replay at 1,300,000

Instruction Card

EXTRA BALL

REPLAYS

Instruction Card Score Card

M-1508-96-F

M-1508-96-E

M-1508-96-A

M-1508-96-A W/PP-1

1 Extra Ball at 900,000

1 Extra Ball at 1,200,000

1 Extra Ball at 1,400,000

ADDITIONAL CARDS

REPLAYS _				EXTRA BALL			
M-1508-H-1	400,000	950,000		M-1508-NN-1	600,000	900,000	1,200,000
M-1508-I-1	450,000	1,000,000		M-1508-OO-1	800,000	1,100,000	1,400,000
M-1508-J-1	500,000	1,000,000	•	M-1508-PP-1	900,000	1,200,000	1,400,000
M-1508-K-1	500,000	1,100,000		M-1508-QQ-1	1,000,000	1,400,000	1,800,000
M-1508-L-1	550,000	1,100,000					
M-1508-M-1	600,000	1,100,000		Ir	etruction C	ard, Novelty	
M-1508-N-1	650,000	1,200,000			1-1508-96-0		
M-1508-O-1	700,000	1,200,000		14	1 1000 00 0		
M-1508-P-1	800,000	1,300,000	•	BLANKS	(3)		
M-1508-Q-1	800,000	1,400,000				ecommended	l levels:
M-1508-R-1	900,000	1,400,000			periodically		
M-1508-S-1	900,000	1,500,000			L 1,300,000		
M-1508-T-1	1,000,000	1,500,000			L 1,500,000		
M-1508-U-1	1,100,000	1,600,000		0 5/12/	_ ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		
M-1508-V-1	1,200,000	1,600,000					
M-1508-FF-1	500,000	800,000	1,100,000				
M-1508-GG-1	600,000	1,100,000	1,300,000				
M-1508-HH-1	700,000	1,400,000	1,600,000				
M-1508-II-1	800,000	1,300,000	1,600,000				
M-1508-JJ-1	900,000	1,400,000	1,600,000				
M-1508-KK-1	1,000,000	1,500,000	1,800,000				

#1215 FLASH GORDON RECOMMENDED SETTINGS

RECOMMENDED REPLAY GAME SAUCER 10,000 LITE SAUCER VALUES RECALL SAUCER 2X, 3X PLAYFIELD VALU OUTLANE SPECIALS RECALL TOP TARGET SPECIAL RECALL BONUS MULTIPLIERS RECALL 2 SIDE TARGETS & FLIP FEED CO 4 DROP TARGETS COLORS REC 1-2-3- ARROW LITE RECALL NUMBER OF REPLAYS PER GAM INLINES EXTRA BALL LITE BALLS PER GAME BALLS PER GAME	JES RECALL OLORS RECALL ALL	SW. 6 SW. 7 SW. 8 SW. 14 SW. 15 SW. 22 SW. 23 SW. 24 SW. 29 SW. 30 SW. 31 SW. 32	ON ON ON ON ON ON ON ON ON ON	5-BALL OFF OFF OFF OFF OFF ON OFF ON OFF ON OFF
REPLAY Instruction Card Score Card Major Mode Match High Score to Date	3-BALL M-1508-96-E M-1508-96-B Self Test Position 16, 17 Set to "03" SW. 28 ON Self Test Position 19 Set to "03"	Set to SW. 28 (-96-E -96-A t Position 1 "03" ON t Position 1	
X-Ball Instruction Card Score Card Major Mode Match High Score to Date		Self Tes Set to SW. 28	-96-A W/P t Position 1 "02" OFF t Position 1	16, 17
NOVELTY Instruction Card Major Mode Match High Score to Date	M-1508-96-G Self Test Position 16, 17 Set to "01" SW. 28 OFF Self Test Position 19 Set to "00"	Set to SW. 28	t Position 1 "01" OFF t Position 1	

ADDITIONAL CARDS FOR PAGE 11

REPLAYS							
M-1508-UU	480,000	720,000	•	M-1508-EEE	380,000	670,000	820,000
M-1508-VV	500,000	740,000		M-1508-FFF	400,000	690,000	840,000
M-1508-WW	520,000	760,000		M-1508-GGG	420,000	710,000	860,000
M-1508-XX	540,000	780,000		M-1508-HHH	440,000	730,000	880,000
M-1508-YY	560,000	800,000		M-1508-III	460,000	750,000	900,000
M-1508-ZZ	580,000	820,000		M-1508-JJJ	480,000	770,000	920,000
M-1508-AAA	600,000	840,000	•	M-1508-KKK	500,000	790,000	940,000
M-1508-BBB	620,000	860,000		M-1508-LLL	520,000	810,000	960,000
M-1508-CCC	640,000	880,000	٠.	M-1508-MMM	540,000	830,000	980,000
M-1508-DDD	660,000	, ,		M-1508-NNN	560,000	850,000	990,000

VIII. ROUTINE MAINTENANCE ON LOCATION:

Self-Test routines are written into the game design. They are particularly useful for routine maintenance. The tests are described below. The first test is automatic and occurs on power-up. This test causes the MPU module A4 to examine itself for failures. Seven flashes of an LED indicates proper operation. The second series of self-diagnostic tests causes the MPU to 'exercise' each of the other modules in such a way as to make their faults, if any, obvious. See Figure III and Page ii.

It is recommended that these tests be used several times a week to check out the games before play. If faults are discovered, they may be corrected on location if the operator has a stock of replacement modules. See "Trouble Shooting on Location."

MPU Module Self-Test:

At power on, the LED on the MPU module flashes once. (Flicker-Flash). After a pause, it flashes six more times and goes out. A power-up tune is played to announce game readiness. This indicates proper MPU operating condition and successful completion of the power-up test.

Game Self-Diagnostic Tests:

- 1. Pressing the Self-Test button inside the door initiates the Self-Test routine. See Figures III and IV. All switched lamps flash off and on continuously.
- 2. Pressing the Self-Test button again causes each digit on each display to cycle from 0 thru 9, and repeat continuously.
- 3. Pressing the Self-Test button again causes each solenoid to be energized, one at a time, in a continuous sequence. Hold both flipper buttons 'in' during this test. The number appearing on the Player Score displays is the same as the number assigned to the solenoid. The sound of a solenoid pulling-in as a number appears indicates proper operation. The absence of sound is improper. If sound is absent, see Page 17 for help in Solenoid identification.
- **4.** Pressing Self-Test button again causes the sound module to play the "Game Over" tune repeatedly.
- 5. Pressing the Self-Test button again causes the MPU to search each switch assembly for stuck contacts. If any are found, the number of the first set encountered is flashed on the Player Score displays. The number remains until the fault is cleared. See Page 17 for help in Stuck Switch identification. Other numbers may follow if more stuck contacts are present. If there are no stuck switches, the Match/Ball in Play display flashes '0'.
- **6.** Pressing the Self-Test button 20 more-times causes the MPU to step thru the threshold and bookkeeping functions described previously and finally to repeat the power-up test. For more rapid exit to power-up, turn the game off, then on. The game is now ready to play.

After successful completion of the Self Diagnostic Test procedure, set the game up for play. Exercise each rollover, thumper-bumper, slingshot, etc., by hand until each switch assembly on the playfield has been checked for proper operation. If actuating a switch assembly results in intermittent or no response, clean contacts by gently closing them on a clean business card or piece of paper and wiping until they wipe clean. Regap, if necessary, to 1/16". Do not burnish or file Gold Plated Switch Contacts.

IX. TROUBLESHOOTING ON LOCATION

The game is designed to make troubleshooting easy. Several simple procedures are given herein that cover the greatest percentage of game failures. They are written for an operator on location and require module replacement. (See Figure III) Symptoms and the action to be taken are given for each type of problem.

If the problem is more complicated and is not solved by following this procedure, more detailed procedures are available from Bally. See the Parts List for ordering information.

SELF DIAGNOSTIC TEST FIGURE IV ROUTINE MAINTENANCE CHECK **REFER TO** 'TROUBLE SHOOTING ON LOCATION' **CORRECT FAULT** POWER-UP: TURN OFF POWER TURN ON POWER SEE SYMPTOM #1, PAGE 15 NO LED ON MODULE A4 FLASHES 7X YES PRESS SELF-TEST BUTTON ON INSIDE OF FRONT DOOR TO ENTER LAMP DRIVER MODULE TEST NO SEE SYMPTOM #2, PAGE 15 ALL FEATURE LAMPS LIGHT. FLASH ON AND OFF? YES PRESS SELF-TEST BUTTON (AGAIN) TO ENTER DISPLAY DRIVER MODULE TEST SEE SYMPTOM #3, PAGE 15 NO ALL DISPLAYS COUNT 0000000 to 9999999 YES PRESS SELF-TEST BUTTON (AGAIN) TO ENTER SOLENOID DRIVER MODULE TEST SEE SYMPTOM #4, PAGE 16 NO ALL SOLENOIDS * PULL-IN** -IN SEQUENCE? PRESS SELF-TEST BUTTON (AGAIN) TO ENTER SOUND MODULE TEST YES (4)PRESS SELF-TEST BUTTON (AGAIN) (5) TO ENTER STUCK-SWITCH TEST **SOUND MODULE PLAYS** 'GAME OVER" TUNE YES NO SEE SYMPTOM #5, PAGE 16 SEE SYMPTOM #6, PAGE 16 NO **ALL SWITCHES* OPEN?** YES *SOLENOID AND STUCK-SWITCH NUMBER IS FLASHED ON PLAYER PRESS SELF-TEST BUTTON 20X OR TURN POWER OFF AND THEN ON. GAME READY TO PLAY. REPEAT ENTIRE TEST IF REPAIR WAS MADE. SCORE DISPLAYS AS AN AID IN TROUBLESHOOTING. See page 17. (6) **HOLD FLIPPER BUTTONS IN DURING TEST.

1A) SYMPTOM: Game does not play power-up tune when power is turned on. General Illumination is present.

ACTION: A) Turn power OFF. Open back box. Locate light emitting diode (LED) on MPU module A4.

B) Turn Power ON. LED must flash 7X to indicate that module A4 is good. Correct flash sequence is flicker/flash-pause-and then six more flashes and LED goes out.

C. If LED does not come on, or does not flash, or flashes, but less than 7X, turn off power. Replace MPU module A4.

CAUTION: Replacement MPU Module must have same Part Number or incorrect operation will result! See Parts List for MPU Module Part Number.

Turn power ON.

D) If game is correct, it is now ready for play. If game is not correct, refer to Module Replacement procedure. (See Parts List.)

2A) SYMPTOM: Not all feature lamps light during game play.

ACTION: A) With power ON, open front door. Press button (Self-Test switch) once. If the game is correct, **all** feature lamps flash ON and OFF.

- B) Carefully raise playfield or open back box to gain access to lamps.
- C) Replace bulbs that do not flash.
- D) If game is correct, it is now ready for play.
- **E)** If game is not correct, turn power OFF. Replace Lamp Driver Module A5. Turn power ON and repeat A.
- F) If game is correct, if is now ready for play.*
- **G)** If game is not correct, turn power OFF. Replace MPU module A4. See CAUTION, 1C. Turn power ON and repeat A.
- **H)** If game is correct, it is now ready for play.* If game is not correct, refer to Module Replacement procedure. (See Parts List.)
- **2B) SYMPTOM:** One or some switched lamps always ON.

ACTION: Repeat 2AA, AB, AE, and AF and, if necessary AG & AH.

3A) SYMPTOM: Display digits improper on **one** or **several**, but less than all Display Driver module(s), A1. Improper: One or several segments always OFF, digits mottled or several segments or digit(s) always ON.

ACTION: A) With power ON, open front door. Press button (Self-Test switch) twice. If the game is correct, each digit on each Display Driver Module A1 (5 used/game) displays the count 1-9 and 0 continuously in all 6 digit positions. Note defective Display Driver modules.

B) Turn power OFF.

CAUTION: High Voltage is supplied to the Display Driver Modules, A1, from the Solenoid Driver/Voltage Regulator Module A3. Wait 30 seconds for High Voltage to Bleed Off.

- **C)** Replace Display Driver module(s) A1. Turn power ON. Repeat A.
- **D)** If game is correct, it is now ready to play.* If game is not correct, refer to Module Replacement procedure. (See Parts List.)
- **3B) SYMPTOM: All** displays improper (all five display Driver modules). Improper: Digit(s) always on or off/segment(s) always on or off, all displays.
 - ACTION: A) Repeat 3AA, and AB.
 - **B)** Replace MPU module A4. See CAUTION NOTE, 1C. Turn power ON. Repeat A.

C) If game is correct, it is now ready to play.* If game is not correct, refer to Module Replacement procedure. (See Parts List.)

SYMPTON: One or several displays always off. 3C)

ACTION: A) Do 3AA, AB, AC, and AD.

B) Repeat 3BB and BC, if necessary.

SYMPTOM: Solenoid(s) do(es) not pull-in during course of game. 4A)

- A) With power ON, open front door. Press button (Self-Test switch) three times.
- B) If game was correct, each solenoid would be energized. A number is flashed on the Player Score displays as each solenoid is pulsed. Note any numbers that do not have the sound of a solenoid associated. See Solenoid Identification Table, Page 17 and Figure V.
- C) Carefully lift the playfield (or open the back box) to gain access to the solenoid. Turn power OFF. Inspect the solenoid.
- D) If a lead is broken off, repair. Repeat A & B. If game is correct, it is now ready for play.* If solenoid wiring was correct, turn power OFF.
- E) Replace Solenoid Driver/Voltage Regulator module A3. See CAUTION NOTE 3AB.
- F) Repeat AA & AB. If game is correct, it is now ready to play.* If game is not correct, turn power OFF.
- G) Replace Sound Module A8.
- H) Repeat AA and AB if game is correct. It is now ready to play. If game is not correct, turn power OFF.
- Replace MPU module A4. See CAUTION NOTE, 1C.
- J) Repeat A & B. If game is correct, it is now ready to play.* If game is not correct, refer to Module Replacement Procedure. (See Parts List.)
- SYMPTOM: Solenoid(s) always energized—Note: if impulse solenoids (ball ejects, 4B) slingshots, thumper-bumpers, etc.) are energized continuously, they are subject to damage. Limit troubleshooting to one minute with power ON, followed by five minutes with power OFF. Repeat as necessary. Replace damaged solenoids.

Do 4AA, AB, AE, AF, AG, AH and if necessary, AI and AJ. ACTION:

SYMPTOM: No Sound. 5)

ACTION:

- A) With Power ON, open front door, press Self-Test switch four times.
- B) Turn volume control clockwise to Max.
- C) If correct, sound will be heard. If incorrect, try seating speaker lead connector (J2) and input connector (J1).
- D) If correct, sound will be heard. If incorrect, refer to Module Replacement procedure."
- **SYMPTOM:** Feature (Drop Targets, etc.) does not score. 6)
 - A) With power ON, open front door. Press button (Self-Test switch) five ACTION:
 - B) If the game is correct, Match/Ball in Play display would flash '0'. If a number appears on the Player Score displays, see Switch Assembly Identification Table. Page 17 and Figure V.
 - C) Carefully lift the playfield. Locate the switch assembly identified from the number. Visually inspect the switch assembly. If the contacts are 'stuck' regap them to 1/16". See section under ADJUSTMENTS. Repeat A & B. If the game is correct, it is now ready to play.* If game is not correct, turn the power OFF.
 - D) Replace MPU module A4. See CAUTION NOTE 1, C.
 - E) Repeat A & B. If the game is correct, it is now ready to play.* If the game is not correct, refer to Module Replacement Procedure. (See Parts List).
- **SYMPTOM:** Game blows fuse(s) repeatedly. 7)

ACTION: See Module Replacement Procedure. F.O. 560

^{*}Turn power On-Off switch OFF and then ON.

GAME #1215 FLASH GORDON (FIGURE V) SOLENOID IDENTIFICATION TABLE

Self Test #	SOLENOID IDENTIFICATION	Self Test #	SOLENOID IDENTIFICATION
01	OUTHOLE KICKER	09	LEFT THUMPER BUMPER
02	KNOCKER	10	RIGHT THUMPER BUMPER
03	SAUCER KICK DOWN	11	SINGLE DROP TARGET PULL DOWN
04	SAUCER KICK UP	12	TOP THUMPER BUMPER
05	SINGLE DROP TARGET RESET	13	LEFT SLINGSHOT
06	4 DROP TARGET	14	RIGHT SLINGSHOT
07	3 DROP TARGET	15	COIN LOCKOUT DOOR
80	IN LINE DROP TARGET	16	KI RELAY (FLIPPER ENABLE)

SWITCH ASSEMBLY SELF-TEST DISPLAY NUMBERS

Switch Self		Switch Self	
Test #	DESCRIPTION	Test #	DESCRIPTION
01	2 LEFT & RIGHT R.O. BUTTONS	21	1 DROP TARGET (TOP)
02	3 SHOOTER LANE R.O. BUTTONS	22	2 DROP TARGET (MIDDLE)
03	TOP SINGLE DROP TARGET	23	3 DROP TARGET (BOTTOM)
04	SHOOTER LANE ROLLOVER	24	TOP TARGET
05	DROP TARGET 50 POINT REB. (2)	25	1st INLINE DROP TARGET
06	CREDIT BUTTON	26	2nd INLINE DROP TARGET
07	TILT (3)	27	3rd INLINE DROP TARGET
80	OUTHÓLE	28	INLINE BACK TARGET
09	COIN III (RIGHT)	29	10 POINT REBOUND (2)
10	COIN I (LEFT)	30	SAUCER
11	COIN II (MIDDLE)	31	RIGHT OUTLANE
12	LOWER RIGHT SIDE TARGET	32	LEFT OUTLANE
13	FLIP FEED LANE (RIGHT)	33	RIGHT SPINNER
14	FLIP FEED LANE (LEFT)	34	LEFT SPINNER
15	UPPER RIGHT SIDE TARGET	35	RIGHT SLINGSHOT
16	SLAM (2)	36	LEFT SLINGSHOT
17	4 DROP TARGET "A" (BOTTOM)	37	TOP THUMPER BUMPER
18	4 DROP TARGET "B"	38	
19	4 DROP TARGET "C"	39	RIGHT THUMPER BUMPER
20	4 DROP TARGET "D" (TOP)	40	LEFT THUMPER BUMPER

NOTE: SLINGSHOT & THUMPER BUMPER COILS WILL BE ENERGIZED WHEN SWITCH IS MADE

#1215 FLASH GORDON

- INDICATES SWITCH ASSEMBLY IDENTIFICATION NUMBERS.
 NOTE: CABINET: 07, 16
 DOOR 06, 09
 10, 11, 16
- INDICATES SOLENOID
 IDENTIFICATION NUMBERS.
 NOTE: DOOR: 15
 BACKBOX: 16
 CABINET: 02




FIGURE V

ASSEMBLY ADJUSTMENTS:

GENERAL:

All switch assemblies consist of leaf springs, contacts, separators, plastic tubing and screws to hold them to the mounting surface. Before attempting to adjust a switch assembly, make sure that these screws are tight. If not, tighten screw closest to the contact end of the leaf spring first. This will prevent the assembly from being secured in such a manner that the leaf springs tend to fan out. In general, all leaf springs are adjusted for a 1/16" gap in the open position and .010" overtravel or wipe in the closed position. All contacts should be in good condition. Unless otherwise instructed, they should be dry or non-lubricated. All contacts should be free of dust and dirt. Contacts, with the exception of the flipper button switch assemblies, are plated to resist corrosion. Filing or burnishing breaks the finish and encourages corrosion. Clean by closing the contacts over a clean piece of paper (e.g. a business card) and wiping gently until the contacts are clean. For the flipper button switch assemblies ONLY: Tarnish can be removed with a contact file followed by a burnishing tool. Severely pitted contacts must be replaced as an assembly. In general, contacts need be cleaned or replaced and adjusted only when they are found to be a source of game malfunction.

X. SERVICE PARTS:

A parts catalogue is available upon request. The catalogue is illustrated and lists all replacement parts for each game manufactured by Bally. Requests should be addressed to:

BALLY MANUFACTURING CORPORATION 2640 WEST BELMONT AVENUE CHICAGO, ILLINOIS 60618 ATTN: PARTS DEPARTMENT

SERVICE HINTS:

The Bally playfield has an improved tuff-coat finish with excellent wearing properties. Its life expectance, as well as play appeal, can be extended by periodic cleaning of the playfield.

DO: Bally recommends you clean your playfield with Wildcat #125 (Wildcat Chemical Co., 1333 W. Seminary Drive, Ft. Worth, Texas 76115). Wildcat #125 is a combination cleaner and polish. Bally has tried and tested this product and found it to be very effective. If Wildcat #125 is not available, Bally suggests you ask your Distributor to order it. Inspect and hand polish the ball in a clean cloth. A chipped ball must be replaced. It can ruin the finish on the playfield in a short period of time.

DON'T: Use water in large quantities, highly caustic cleaners, abrasive cleaners or cleaning pads on the playfield. Do not allow a wax or polish build up. Waxes yellow with age and spoil play appeal.

XI. PARTS LIST #1215 FLASH GORDON

MISCELLANEOUS Transformer (Domestic or Export)	. E-125-22
ASSEMBLY COILS Coin Lockout Flipper (3) Knocker Outhole Kicker Thumper-Bumper (3)	. AQ-25-500/ 34-4500 . AR-26-1200 . AN-26-1200
Sling-Shot (2) Drop Target Reset (3) Single Drop Target Pulldown Single Drop Target Reset Saucer Kickup Saucer Kickdown PLAYFIELD PARTS	AN-26-1200 NO-26-1900 CE-31-2000 AO-27-1300 AO-27-1300
MODULES Lamp Driver A5 Display Driver A1 (1 used) Display Driver A1 (4 used) Solenoid Driver/Voltage Regulator A3 MPU A4 Transformer & Rectifier A2 Rectifier Board (Part of A2) Squawk & Talk Auxiliary Lamp Driver A9 Strobe	. AS-2518-21 . AS-2518-58 . AS-2518-22 . AS-2962-24 . AS-2877-6 . AS-2518-54 . AS-3107-1
REPAIRS PROCEDURES/AIDS Module & Component Replacement	
MODULE COMPONENTS SEE MODULE PARTS LIST	
MODULE COMPONENT STARTER KITS (Each Kit contains an assortment of the most needed electronic parts for use Kit #558—For Rectifier Board (Part of A2) Kit #503—For MPU Board A4 (Less Memory U1-U6) Kit #492—For Solenoid Driver/Voltage Regulator A3 Kit #493—For Display Driver A1 Kit #494—For Lamp Driver A5	in Module repair.)

A4: MPU MODULE COMPONENT PARTS LIST


ITEM	REFERENCE DESIGNATION	BALLY PART#	DESCRIPTION
1	A4 (see note 1)	AS-2962-24	MPU Module Complete.
2	A4 (see note 2)	AS-2518-35	MPU Module less Program Memory, U1-6 incl.
3-32	See Schematic		Resistors, See schematic for value
33	C14, C15	E-00586-0067	Capacitor, 470 PFD, 1kv
34	C18	E-00586-0088	Capacitor, .05 MFD, 16V
35	C16	E-00586-0081	Capacitor, .1 MFD, 100V
36	C4, C5	E-00586-0073	Capacitor, 4.5 MFD, 25V
37	C3, C6-C13, C17, C81	E-00586-0085	Capacitor, .01 MFD, 25V
38	C79, C41-C67	E-00586-0083	Capacitor, 470 PFD, 50V
39	C19-C31, C78, C33-C40	E-00586-0082	Capacitor, 390 PFD, 50V
40	C1, C2, C68-C77	E-00586-0084	Capacitor, 820 PFD, 50V
41	C32	E-00586-0077	Capacitor, 3000 PF, 1kv
43	Q5	E-00585-0023	Transistor PNP (MPS-3702)
44	Q1, Q2	E-00585-0031	Transistor (2N3904)
47	CR44	E-00587-0006	Diode (IN4004)
48	CR1-CR7, CR11-CR43,	E-00587-0014	Diode (IN4148)
40	CR45-CR49	L-00307-0014	
49	CR8	E-00679	LED (Green)
50	VR1	E-00598-0008	Diode Zener (8.2V, IN9598)
52	L1, L2	E-00604-0003	Inductor, 22 Micro Hy.
53	U12	E-00620-0004	Timer (555)
54	U19	E-00620-0005	Quad 2 Input (4011)
55	U9	E-00620-0028	MPU I.C. (6800)
56	U10, U11	E-00620-0029	PIA I.C. (6820)
57	U7 [^]	E-00620-0030	RAM I.C. (6810)
59	U20	E-00620-0032	HEX Buffer I.C. (14502B)
60	U14, U18	E-00620-0033	HEX Inverter (4049B)
61	U15	E-00620-0034	Quad Memory Drive (MC3459L)
62	U16	E-00620-0035	Dual Monostable (9602)
64	U17	E-00620-0041	Quad 2 Inputs (74L00N)
65	U8	E-00620-0042	RAM (C MOS, P5101L-3)
68	BT1, BT2, BT3	E-00628-0003	Battery
70	S33	E-00658-0001	Push Button Switch
71	S1-S8, S9-S16, S17-S24, S25-S32	E-00677	DIP Switch
73		E-00712	24 Pin Socket
74		E-00712-0001	40 Pin Socket
75		E-00712-0003	22 Pin Socket
77	J2	E-00715	15 Pin Wafer Connector
78	J1	E-00715-0004	28 Pin Wafer Connector
79	J3, J5	E-00715-0017	16 Pin Wafer Connector
80	J4 [°]	E-00715-0018	19 Pin Wafer Connector
81	J5	E-00715-0024	17 Pin Wafer Connector

NOTE 1:

When ordering, fill in dash number. For example, AS-2962-0: LOST WORLD, AS-2962-2: SIX MILLION DOLLAR MAN, AS-2962-3: PLAYBOY, AS-2962-4: VOLTAN, AS-2962-5: SUPERSONIC, AS-2962-6: STAR TREK, AS-2962-7: KISS, AS-2962-8: PARAGON, AS-2962-9: GROUND SHAKER, AS-2962-10: HARLEM GLOBETERS, AS-2962-12: DOLLY PARTON, AS-2962-13: SILVERBALL MANIA, AS-2962-18: MYSTIC, AS-2962-20 HOTDOGGIN, AS-2962-22: SKATEBALL, AS-2963-23: FRONTIER, AS-2962-21: XENON, AS-2962-24: FLASH GORDON

NOTE 2: Order replacement memory chips U1-U6, specifying game, socket and part number stamped on chip.


AS-2518-23 LAMP DRIVER MODULE



A5: LAMP DRIVER MODULE COMPONENT PARTS LIST

ITEM	REFERENCE DESIGNATION	BALLY PART #	DESCRIPTION
1	A5	AS-2518-23	Lamp Driver Module, Complete
2	R71-R79	E-00105-242	Resistor, 20kΩ, 5%, ¼W
3	R1-R60, R70	E-00105-0237	Resistor, 2kΩ, 5%, ¼W
4	R61-R69	E-00105-0256	Resistor, 2.2MΩ, ¼W
5	C1	E-00586-0065	Capacitor, .01 MFD, 500V
6	Q4-Q7, Q11-Q14, Q18-Q21, Q25-Q32, Q36-Q39, Q43-Q46, Q50-Q53, Q57-Q60	E-00585-0014	SCR, 2N5060
7	Q1-Q3, Q8-Q10, Q15-Q17, Q22-Q24, Q33-Q35, Q40-Q42, Q47-Q49, Q54-Q56	E-00585-0029	SCR, MCR106-1
8	U1-U4	E-00620-0037	I.C., Decoder, 14514B
9	J1, J3	E-00715-0004	28 Pin Wafer Connector
10	J4	E-00715-0024	17 Pin Wafer Connector
11	J2	E-00715-0014	23 Pin Wafer Connector
12	TP1, TP2, TP3	P-05399	Test Clip

AS-2518-21 CREDIT DISPLAY DRIVER MODULE



A1: 6 DIGIT DISPLAY DRIVER MODULE COMPONENT PARTS LIST

ITEM	QTY.	REFERENCE DESIGNATION	BALLY PART #	DESCRIPTION
1	1		P-2948-296	P.C. Board, M-645-392
3	7	R1, R3, R5, R7, R9, R11, R34	E-105-331	Resistor, 100K Ω
4	13	R14, R16, R18, R20, R22, R24, R26, R35, R36, R37, R38, R39, R40	E-105-227	Resistor, 300K Ω
5	6	R43, R44, R45, R46, R47, R48	E-105-228	Resistor, 9.1K Ω
6	7	R13, R15, R17, R19, R21, R23, R25	E-105-229	Resistor, 1.5K Ω
7	7	R27, R28, R29, R30, R31, R32, R33	E-105-222	Resistor, 1.2K Ω
8	1	R41	E-105-231	Resistor, 39K Ω
9	1	R42	E-105-271	Resistor, 240K Ω
10				
11	1	C2 .	E-586-65	Capacitor, .01 MFD, 500V
13	6	Q7, Q8, Q9, Q10, Q11, Q12	E-585-32	Transistor (2N5401)
14	13	Q1, Q2, Q3, Q4, Q5, Q6, Q13, Q14, Q15, Q16, Q17, Q18, Q19	E-585-33	Transistor (MPS-A42)
16	1	VR1	E-598-7	Zener Diode, 110V
17	i	U1	E-620-38	I.C. Decoder
18	•	01	L 020 00	i.o. becoder
19	2	J1	E-715-34	10 Pin Wafer Pin Connector
21	ī	DS1	E-680	Digital Display Panel
22	2		M-1836	Hi-Lo Screw, W/H
23	1		P-2399	Display Mounting (Top)
24	1		P-2399-1	Display Mounting (Bottom)
26	6	R2, R4, R6, R8, R10, R12	E-105-287	Resistor, 2.2K Ω
27	6	R49, R50, R51, R52, R53, R54	E-105-242	Resistor, 20K Ω
28	As Req'd			Wire Jumper
29	1 '	C1	E-586-85	Capacitor, .01 MFD, 25V


	•	

A3: SOLENOID DRIVER/VOLTAGE REGULATOR MODULE COMPONENT PARTS LIST

ITEM	REFERENCE DESIGNATION	BALLY PART #	DESCRIPTION
1	A3	AS-2518-22	Solenoid Driver/Voltage Regulator Module, Complete
3-14	Resistors		Resistor, See Schematic for value.
15	RT1	E-00599-0014	Pot. (Linear) 25K
17	C25, 29	E-00586-0014	Capacitor, .1 MFD, 20V
18	C26	E-00586-0059	Capacitor, 160 MFD, 350V
19	C24	E-00586-0063	Capacitor, 2 MFD @ 25V
20	C23	E-00586-0062	Capacitor, 11700 MFD, 20V
21	C1-C8, C11-C21	E-00586-0064	Capacitor, .002 MFD, 1kv
22	C27, C28	E-00586-0065	Capacitor, .01 MFD, 500V
24	K1	E-00146-0795	Relay, Printed Circuit
25	Q1-Q19	E-00585-0034	Transistor, SE9302
26	Q22, Q23	E-00585-0041	Transistor, 2N3440
27	Q21	E-00585-0042	Transistor, 2N3584
28	Q20	E-00710	+5V Regulator, LAS1405 or 78H05KC or LM323K
30	CR1-CR21	E-00587-0015	Diode (IN4004)
31	VR1	E-00598-0010	Diode, Zener 140V, IN5275A
33	U1, U3, U4	E-00681	I.C. Transistor Array, CA3081
34	U2	E-00620-0039	I.C. Binary to 1/16 Decoder, 74L154
36		E-00592-0002*	Relay Socket
37		M-1839*	Relay Holder
39		E-00682	Heat Sink, TO5
40		E-00682-0001	Heat Sink, TO66
41		E-00682-0002	Heat Sink, TO3 Case
42		E-00715-0039	15 Pin Wafer Connector
43		E-00715-0016	12 Pin Wafer Connector
44		E-00715-0020	25 Pin Wafer Connector
45		E-00715-0033	9 Pin Wafer Connctor
55		M-1838	Shield-Plexiglass
59		E-00148-0021	Fuse Clips
60	F1	E-00133-0029	Fuse 8 AG-3/16 Amp.
23	C22	E-00586-0085	Capacitor, .01 MFD, 25V

^{*}USED WITH ITEM 24, E-00146-0791, PLUG IN RELAY ONLY


A2: POWER TRANSFORMER MODULE



COMPONENT PARTS LIST

ITEM	REFERENCE DESIGNATION	BALLY PART #	DESCRIPTION
0	A2	AS-2877-6	Power Transformer Module,
			Complete
1		AS-3071-2	Transformer
2		E-148-25	Fuse Holder
3	A2	AS-2518-54	Power Module Assy.
4		M-1829-4	Hinged Support
5		M-1829-3	Edge Holder
6		M-1829-5	Spacer
7		P-6442-244b	Fuse & Connect Brkt.
8		P-6442-246	Chassis
9		RLPP-832-1812	Screw
10		RLPP-1032-1806	Screw
11		P-2692-2	Shield
12		M-469-936a	High Voltage Sticker
13		E-133-24	3A S.B. Fuse
14		M-1834	H. S. Compound

AS-2518-54 RECTIFIER BOARD ASSEMBLY



(Part of) A2: POWER TRANSFORMER MODULE COMPONENT PARTS LIST

ITEM	REFERENCE DESIGNATION	BALLY PART #	DESCRIPTION	
0	A2	AS-2877-6	Power Transformer Module, Complete	
1	P/O A2	AS-2518-54	Rectifier Board Assembly, Complete	
3	R1	E-00104-0092	Resistor, 10%, 600 Ohm, 10W	
4	R2	E-00104-0091	Resistor, 25 Ohm, 5W	
5	R3	E-00105-0226	Resistor, 5%, 100K Ohm, 1/4W	
5 7	VR1	E-00623	Varistor	
8	CR5, CR6, CR7, CR8 .	E-00587-0022	3A Diode	
9	CR1, CR2, CR3, CR4	E-00587-0015	Diode (IN4004)	
10				
11	Used with BR1-2	P-1973-480	Spacer	
12	BR1, BR2	E-00602-0006	Bridge Rectifier	
15	F2	E-00133-0028	Fuse, 3/4A, 250V, 3AG	
16	F3	E-00133-0004	Fuse, 4A, 32V, 3AG	
17	F4	E-00133-0005	Fuse 5A, 32V, 3AG	
18	F1, F5	E-00133-0027	Fuse, 20A, 32V, 3AG	
19				
20	J1	E-806-9	9 CKT Socket Header	
21	TP1, 2, 3, 4, 5	P-05399	Test Clip	
22	J2, J6	E-805-6	6 CKT Pin Header	
23	J4, J5	E-805-9	9 CKT Pin Header	
24	J3	E-805-12	12 CKT Pin Header	
25	F2, 3, 4	E-00148-0021	Fuse Clips	
26	F1, 5	E-00148-0022	Fuse Clips (Low Resistance)	


AS-2518-61 SQUAWK & TALK COMPONENT PARTS LIST


ITEM	REFERENCE DESIGNATION	BALLY PART #	DESCRIPTION
1	PWB	P-2948-446a	M-645-577a
2	U10	E-620-171	AD 558 DAC
3	Used with U2 thru U6	E-712	24 Pin I.C. Socket
4	U7, 11	E-620-29	6821 P.I.A.
5	U8	E-620-167	Tms 5200 Speech
Ü		E 020 107	71110 0200 Op00011
7	U12	E-620-166	AY3-8912 Sound
8	U8	E-620-30	6810 RAM (See Note 1)
9	U16	E-620-33	4049 Hex Inverter
10	U13, 14	E-620-126	LM3900
11	U15	E-620-169	74LS14 Schmidt Inverter
12	U17	E-620-168	74LS155
13	U18	E-620-127	TDA 2002 Power Amp
14	VR1	E-710	LM323, 5V Regulator
15	VR2	E-620-165	7905, -5V Regulator
16	R10, 19, 29, 42, 50, 63-6		
	71-78, 55	E-105-185	Resistor, ¼ W, 10K
17	R2-5, 8	E-105-238	Resistor, ¼ W, 5%, 3.3K
18	R20, 43	E-105-343	Resistor, 1/4 W, 5%, 820K
19	R21, 44	E-105-310	Resistor, 1/4 W, 5%, 390K
20	R13, 22, 38, 41, 45	E-105-225	Resistor, ¼ W, 200K
21	R23, 24, 46, 61	E-105-226	Resistor, ¼ W, 5%, 100K
22	R30, 53, 56, 80	E-105-237	Resistor, ¼ W, 5%, 2K
23	R47	E-105-151	Resistor, ¼ W, 5%, 2.7K
24	R25, 26, 27, 32, 49, 59,		Resistor, ¼ W, 5%, 1m
25	R33	E-105-313	Resistor, 1/4 W, 5%, 91K
26	R37	E-105-245	Resistor, 1/4 W, 5%, 30K
27	R12, 36, 57, 58, 81	E-105-230	Resistor, ¼ W, 5%, 1K
28	R51	E-105-344	Resistor, 1/4 W, 5%, 750K
29	R52	E-105-228	Resistor, 1/4 W, 5%, 9.1K
30	R16	E-105-203	Resistor, 1/4 W, 5%, 130K
31	R11	E-105-248	Resistor, ¼ W, 5%, 150K
32	R15	E-105-161	Resistor, ¼ W, 5%, 220K
33	R14	E-105-346	Resistor, 1/4 W, 5%, 1.8K
34	R17, 18, 39, 40	E-105-347	Resistor, 1/4 W, 5%, 910K
35	R1	E-105-243	Resistor, ¼ W, 5%, 27K
36	R68	E-105-311	Resistor, ¼ W, 5%, 510 Ohm
37	R34	E-105-211	Resistor, ¼ W, 5%, 2.2 Ohm
38	R31	E-105-303	Resistor, ¼ W, 5%, 220 Ohm
39	R79	E-105-345	Resistor, 1/4 W, 5%, 7.5K
40	R35	E-105-196	Resistor, ¼ W, 5%, 1. Ohm
42	R7	E-105-223	Resistor, 1/4 W, 5%, 8.2K
43	C2, 5-8, 10, 11, 17, 18, 4		Capacitor, Ceramic, .01 uF 25V
44	C23, 35	E-586-130	Capacitor, Ceramic, .47 uF 16V
45	R9	E-105-271	Resistor, ¼ W, 5%, 240K
46	R6	E-105-342	Resistor, 1/2 W, 470 Ohm
47	C19, 24, 25, 28, 31, 34, 4		Capacitor, Electrolytic, 1 uF, 25V
48	C19, 24, 25, 28, 31, 34, 4 C12, 13, 30, 33, 26, 40,	IE E 000-30	Capacitor, Lieutorytto, 1 ur, 20 v
	39,41, 46, 45	E-586-89	Capacitor, Ceramic, .1 uF, 25V
49	C9, 20	E-586-83	Capacitor, Ceramic, 470pF, 50V
50	C32	E-586-120	Capacitor, Ceramic, 69pF

AS-2518-61 SQUAWK & TALK COMPONENT PARTS LIST

ITEM	REFERENCE DESIGNATION	BALLY PART #	DESCRIPTION
51	C21	E-586-68	Capacitor, Ceramic, 100pF
52	C15	E-586-135	Capacitor, Electrolytic, 10 uF, 16V
53	C16, 22	E-586-73	Capacitor, Tantalum, 4.7 uF, 25V
54	C27	E-586-136	Capacitor, Electrolytic, 1000 uF, 16V
55	C29	E-586-124	Capacitor, Electrolytic, 470 uF, 6V
56	C3, 4	E-586-121	Capacitor, Ceramic, 27pF
57	C14	E-586-123	Capacitor, Electrolytic, 4700 uF, 25V
58	C37, 38	E-586-147	Capacitor, Electrolytic, 330 uF, 50V
59			
60	J1	E-736-15	15 Pin Wafer Connector (156)
61	J2	E-736-6	6 Pin Wafer Connector (156)
62	Used with VR1	E-682-11	Heatsink, 6053B
63	Used with U18	E-682-8	Heatsink, 6030B
64		P-5399	Test-points
65	Sw. 1	E-658-1	P.C.B. Switch
66	CR7, 8, 10	E-587-15	Diode (1N4004)
67	CR1, 5, 6, 9, 11	E-587-14	Diode (1N4148)
68	Y1	E-744-5	Crystal, 3.579
69	LED1	E-679	LED
70	Q1-2	E-585-31	Transistor, 2N3904
71	Used with U10	E-712-16	Socket I.C. 16 Pin
72	CR2-4	E-587-22	Diode, VR332
73	U1	E-620-125 Or 128	6808 or 6802
			(See Note 1) Microprocessor
74	Used with U1, 7, 11	E-712-1	Socket I.C. 40 Pin
75	Used with U8, 9, 12	E-712-28	Socket I.C. 28 Pin
76	Used with U18, VR1	LSPR-00632-1106	Screw
77	Used with VR1, U18	N-00632-2112	Nut
78	J3	E-766-20	Header, 20 Pin
79	R48	E-105-312	2.4K, 1/4 W, 5%, Resistor
80	C36, 43	E-586-63	2 uF, 16V, Capacitor
81	R69, 70	E-599-16	Pot. 1K
82	C1	E-586-148	47 uF Electrolytic Capacitor
83	R28, 54	E-105-341	82K Resistor
84	Used with U18, VR1	M-1834	Thermal compound
85	•		Jumpers See Notes


SQUAWK & TALK AS-2518-61





ITEM	REFERENCE DESIGNATION	BALLY PART #	DESCRIPTION
1		0017-00042-0231	3/4" Standoff
2		A080-91359-B645	P.C. Board-41/2" x 51/4"
3		0064-030XX-XXXX	IN4004 400V. 1A Diode
4		0062-287B3-1XXX	180K Ohm 1/4 W. 5% Carbon
5		0062-227A1-1XXX	10K Ohm 1/8 W. 1% Carbon
6		0069-185XX-XAHX	Transformer Step-up SEC 540T
7		0062-141P5-41XX	300 Ohm 20 W. 5% WW Resistor
8		0069-156XX-XX1X	Flash Tube G.E. FT19-30K
9		0645-00116-0000	Strobe Lamp Bracket
10		0017-00042-0233	Tension Clip
11		0017-00101-0555	6-32 Self-Tapping Screw w/Washers
12		0017-00042-0232	13/8" Standoff
13		0062-323B3-1XXX	1 M Ohm 1/4 W. 5% Carbon
14		0061-212N6-5E1X	22 MF 250V. 20% Axial Capacitor
15		0065 552XX-XXDX	C108C41 SCR PNPN 300V.
16		0062-179B3-1XXX	1K Ohm ¼ W. 5% Carbon
17		0069-131XX-XXGX	M0C3011 Optical Coupler
18		0645-00802-0000	.1 MF 200V. 10% Mylar
19		0062-144B3-1XXX	330 Ohm 1/4 W. 5% Carbon
20		E-736-8 (Bally #)	Connector 8 Pin
21		0069-157XX-XX1X	Reflector
22		0645-00918-0000	Grommet
		32	

AS-2518-58 DISPLAY DRIVER MODULE




A1: 7 DIGIT DISPLAY DRIVER MODULE

COMPONENTS PARTS LIST


ITEM	QTY.	REFERENCE DESIGNATION	BALLY PART #	DESCRIPTION
1	1		P-2948-424	P.C. Board, M-645 546
3	8	R1, R3, R5, R7, R9, R11, R34, R56	E-105-331	Resistor, 100K Ω
4	15	R14, R16, R18, R20, R22, R24, R26, R35, R36, R37, R38, R39, R40, R58, R62	E-105-227	Resistor, 300K Ω
5	7	R43, R44, R45, R46, R47, R48, R55	E-105-228	Resistor, 9.1K Ω
6	9	R13, R15, R17, R19, R21, R23, R25, R61, R60	E-105-229	Resistor, 1.5K Ω
7	7	R27, R28, R29, R30, R31, R32, R33	E-105-222	Resistor, 1.2K Ω
8	1	R41	E-105-231	Resistor, 39K Ω
9	1	R42	E-105-271	Resistor, 240K Ω
10	1	R63	E-105-248	Resistor, 150K Ω
11	1	C2	E-586-65	Capacitor, .01 MFD, 500V
13	7	Q7, Q8, Q9, Q10, Q11, Q12, Q21	E-585-32	Transistor (2N5401)
14	15	Q1, Q2, Q3, Q4, Q5, Q6, Q13, Q14, Q15, Q16, Q17, Q18, Q19, Q20, Q22	E-585-33	Transistor (MPS-A42)
15	2	CR1-2	E-587-14	Diode (IN4148)
16	1	VR1	E-598-7	Zener Diode, 110V (IN3045A)
17	1	U1	E-620-38	I.C. Decoder (MC14543)
18				
19	2	J1	E-736-10	10 Pin Wafer Pin Connector (KK-156)
21	1	DS1	E-680-7	7 Digital Display Panel
22	2		M-1836	Hi-Lo Screw, W/H
23	1		P-2399	Display Mounting (Top)
24	1		P-2399-1	Display Mounting (Bottom)
25	3	TP1-3	P-5399	Test Clip
26	7	R2, R4, R6, R8, R10, R12, R57	E-105-287	Resistor, 2.2K Ω
27 28	6	R49, R50, R51, R52, R53, R54	E-105-242	Resistor, 20K Ω
29	1	C1	E-586-85	Capacitor, .01 MFD, 25V

AS-2518-52 AUXILIARY LAMP DRIVER



A9: AUXILIARY LAMP DRIVER COMPONENT PARTS LIST

ITEM	QTY.	REFERENCE DESIGNATION	BALLY PART NO.	DESCRIPTION
1	1		P-2948-504	P.C.B. (M-645-512)
2	1	U1	E-620-134	Quad Flip Flop
3	4	U2 Thru U5	E-620-108	BCD to Decimal Decoder
4	28	Q1 Thru Q28	E-585-29	S.C.R.
5	28	R10 Thru R37	E-105-237	Resistor, 2K \O, 1/4 W, 5%
6	8	R1-4, R6-9	E-105-242	Resistor, 20K Ω, ¼ W, 5%
7	1	R5	E-105-173	Resistor, 2.2M, ¼ W, 5%
8	1	C1	E-586-85	Capacitor, $.01\mu$ f, 25V, $\pm 20\%$
9	1	J1	E-736-15	Connector, KK156 15 Pin
10	1	J2	E-736-18	Connector, KK156 18 Pin
11	2	J3	E-736-10	Connector, KK156 10 Pin
12	2	TP1, TP2	P-5399	Test Point
13	25	•	M-1777-126	Jumper




VECTOR DRAWING FOR FLASH GORDON UP AND DOWN EJECT SAUCER


Ball from saucer kicking down to left side of left thumper bumper.

Ball from saucer kicking up in approximate direction of arrows.

				•	
					•
					,
•					
					•
					•
		•			
					•
				,	
•					
	s Sec	A STATE OF THE STA	management of account about the contract of	* *	

AS 2877 -X_TRANSFORMER POWER ASSEMBLY_ SEE NOTE I AS-3071-X TRANSFORMER ASSY. --CABINET WIRING NOTE I OFF F5,20A YEL FI 3A, SB OCCUPANTA OF THE PROPERTY OF T 6.5 VAC 2 CN CONVIENCE BLK FRONT DOCR BITERLOCK 12 SPARE COMMON ORN/BLA F2, 3/4A NOT USED 'N ALL GAME KED IN40046 CHI CR2 :15 VAC 170 REU ORN/BLK 3 170 VAC WH/BLK 3 CR3 120 VAC 4 F4,5A GRN FLI 5 0000 49 ORN RED/BLK 49 VAC 6 COLAMON O 7 [1<u>6</u>] VRI 8 F1,20A PUR/6LK 100 VAC (E 122-142) (9.4 VAC) (E122-141) (8.2 VAC) PUR 9 BLK/BLU 3 115 VAC JUMPERS SHOWN 10 FOF 115 VAC 120 VAC (SEE TABLE A FOR CTHER VOLTAGES) F3,4A NITES CRE I. SEE GAME MANUAL OF SPECIFIC GAME FOR CORRECT DASH / PART NUMBER. CRS TABLE "A" 115 VAC , 2-8 , 3-6 , 7-1 120 VAC, 2-8, 4-6, 7-11 220 VAC , 4-8 , 7-9 240 VAC, 4-8, 7-11 OPER. DEPT. DESCRIPTION TOOL NO. NO. LET. CHANGE DA







- I. USE BALLY PART NO. E-713 FOR 115-120 VAC.
- 2. USE BALLY PART NO. E-713-1 FOR 220-240 VAC.
- 3. # INDICATES AID TEST POINT.


то	JI PIN	то	J I PIN
A4J3-9		A4 J3 -3	11
A4J3-10	2	A2J2-4	15
A4J3-11	3	A3J2-8	16
A4J3-12	4	A2J2-6	17
A4J3-I3	5	A2J2-3	18_
A4J3-I4	6	A4J3-1	19
A4J3-15	7	A3J2-7	20
A4J3-16	8	SPEAKER	9
A4J3-2	10	A8J2 - I	12
OOR PLUG		A8J2-2	13


A7 CABINET ASS'Y. WIRING NOTE: DIODES ARE IN4004, (E-88


OPER. DEPT. DESCRIPTION TOOL NO.















* INDICATES "AID" TEST POINT.


NOTES:

- I. UNLESS OTHERWISE SPECIFIED ALL RESISTORS ARE ± 5 %, 1/4 W.
- 2. PREFIX ALL REFERENCE DESIG. WITH ASSEMBLY REFERENCE DESIG. "A I".

OPER. DEPT. DESCRIPTION TOOL NO.









NOTES


- I. * INDICATES "AID" TEST POINT.
- 2. REMOVE A3J4 BEFORE USING AS AID TEST POINT
- PREFIX ALL REFERENCE DESIGNATIONS WITH "A4"
- 4. EXACT CHIP COMPLEMENT USED IN SOCKETS UI THRU U6 CAN VARY FOR DIFFERENT GAMES AND PRODUCTION LOTS.

 TABLES OF MEMORY CHIPS AND CORRESPONDING JUMPERS FOR DIFFERENT GAMES AVAILABLE FROM BALLY FIELD SERVICE DEPARTMENT.







CHANGE



OPER. DEPT. DESCRIPTION TOOL NO. NO. LET. CHANGE





TOOL No.

DESCRIPTION

OPER. DEPT.

